

VB

Box Type Union



MODEL	PORT1	PORT2
VBH05-5/32-5/32P	5/32"	5/32"
VBH07-1/4-1/4P	1/4"	1/4"
VBH10-1/4-1/4P	1/4"	1/4"
VBH12-1/4-1/4P	1/4"	1/4"
VL05-5/32-5/32P	5/32"	5/32"
VL07-1/4-1/4P	1/4"	1/4"
VL10-1/4-1/4P	1/4"	1/4"
VBE07-1/4-1/4P	1/4"	1/4"
VBE10-1/4-1/4P	1/4"	1/4"
VBE12-1/4-1/4P	1/4"	1/4"

VB

Vacuum Switch

Box Type Union With Vacuum Switch



MODEL	PORT1	PORT2
VBH05-5/32-5/32S	5/32"	5/32"
VBH07-1/4-1/4S	1/4"	1/4"
VBH10-1/4-1/4S	1/4"	1/4"
VBH12-1/4-1/4S	1/4"	1/4"
VL05-5/32-5/32S	5/32"	5/32"
VL07-1/4-1/4S	1/4"	1/4"
VL10-1/4-1/4S	1/4"	1/4"
VBE07-1/4-1/4S	1/4"	1/4"
VBE10-1/4-1/4S	1/4"	1/4"
VBE12-1/4-1/4S	1/4"	1/4"

VUSM

Mechanical Vacuum Switch

MODEL	PORT
VUSM10-5/32	5/32"
VUSM10-1/4	1/4"

